

## Outdoor Gas Oven Clearance to non combustible construction

As stated on Page 27 of the installation instructions, a minimum of 61 cm (24 inches) clearance from the back of the grill to non combustible construction is required for the lid to fully open. This is referring to a barbecue grill top. When the lid of a grill is opened fully the top extends well beyond the back of the base of the grill. This statement applies only to grills and it is part of the written test standard used for certification by CSA, the agency that was used to receive our product certification. This does not apply to our ovens since there is no lid, only the chimney that requires adequate clearance. **We recommend 24" inches minimum clearance from the top of the chimney to any overhanging objects. We recommend 2"-4" inches minimum clearance from the side vents and 2" inches minimum from the rear heat shield.** The heat shield is cool to the touch when the oven is running, the sides; top and chimney is VERY hot.

